# GUANGZHOU VTS USER'S GUIDE

GUANGZHOU MARITIME SAFTY ADMINISTRATION OF P.R.C

#### SYSTEM SUMMARY

#### GUANGZHOU VTS CENTER:

Postcode : 510700

Add: No. 7, Lixiang Road, Huangpu, Guangzhou, P. R. China.

Fax: 020-82280564, 020-82354209

Tel: 020-82272372,020-82280556

Eml: gzjgzx@gdmsa.gov.cn

Working time : 24 hours.

Working language: Mandarin or Cantonese or English.

VTS Service Area: Pearl River waters within the BOUNDARY of GUANGZHOU VTS, i.e. southeast to Guishan southeastern reporting line, north to Daihaozhou channel Guangzhou port east No. 1 lightbuoy reporting line and Tiezhuang channel No. 75 lightbuoy reporting line.

VTS Participating Vessels: Vessels equipped with the communication equipment required by the relevant international conventions and/or national rules and regulations, and vessels monitored by VTS as required by the competent authorities. The following vessels have to report to VTS:

 All foreign vessels; 2. Chinese vessels more than 500 tons;
 Passenger vessels with a carrying capacity of more than 30 passengers; 4. Other vessels as required by the competent authorities.

VHF PROCEDURES		
SECTOR: GUANGZHOU VTS Zone consist of 2 sectors: The sector outside of HUMEN BRIDGE VHF CH09 The sector inside of HUMEN BRIDGE VHF CH08	NOTE: Inbound vessels which pass through HUMEN BRIDGE reporting line should report on VHF CH 09, and then switch to VHF CH 08 and keep continuous watch.	
Vessel should call "GUANGZOU VTS" and keep watch on appropriate VHF channel.	Outbound vessels which pass through HUMEN BRIDGE	
Other working channels of Guangdong VTS: VHF CH01,VHF CH21,VHF CH64	In the case of distress communications, all other communications should be suspended and should not interfere with the distress communications.	

## Pre-Arrival Notifications

### Pre-Arrival Notifications:

Cargo vessels more than 3000GT, Dangerous goods vessels more than 1000GT should forecast not less than 24 hours before the intended entry to Guangzhou VTS area (or on departure from the last port of call if the voyage takes less than 24 hours )

To:GUANGZHOU VTS

**Giving** :1. Name and call sign 2. Type of vessel 3. Name, address and telephone number of the vessel's owner or agent or charterer 4. Nationality 5. Port of registry 6. Length overall 7. Breadth 8. Maximum height 9. Gross tonnage 10. Number of main engine, power and speed 11. Main type and weight of cargo 12. Class and quantity of Dangerous goods (if any) 13. Maximum draught on arrival 14. Number of crew/passengers 15. ETA 16. last port of call.

Via:Internet (e-form submission or e-mail) or FAX.

Ships Reporting		
Position reports:	There are 11 reporting lines in GUANGZHOU VTS area:	
To:GUANGZHOU VTS	<ol> <li>GUISHAN SOUTHEASTERN REPORTING LINE (L1)</li> <li>An arc with Guishan Pilotage Anchorage (position 22°07′54″N, 113°46′50″E) as the center</li> </ol>	
Giving:1 Vessel Name & call sign	and 10 nautical miles as radius, joint between Dangan Channel (position 22°08′ 54.5″ N,113	
2. Position	$^{\circ}57'$ 30" E) and southwest waters of Dongao Island (position 22°00' 16" N,113°40' 00" E).	
3.Actual Max draft	<ul> <li>2. TONGGU REPORTING LINE (L2)</li> <li>A line joint between Niulijiao light beacon of Neilingding island (position 22° 25′01″ N, 113° 46′56″</li> </ul>	
Via: VHF	E) and Jiyijiao light beacon of Dayushan island (position 22°13'00" N, 113°50'12" E) (HKSAR waters	
	excluded)	
	3. GUISHAN WESTERN REPORTING LINE (L3)	
	A line joint between position 22° 20′ 00″ N, 113° 40′ 00″ E and position 22° 00′ 16″ N/113°	
	40′00″E.	
	4. LINGDING WESTERN REPORTING LINE (L4)	
	A line joint between position 22° 20′ 00″ N,113° 40′ 00″ E and position 22° 39′ 00″ N,	
	113° 40′ 00″ E.	

Ships Reporting		
5. LINGDING EASTERN REPORTING LINE (L5)	Arrival report	
A line joint between Dongbaohe estuary (position 22° 44′ 08″ N,113° 44′	On arrival at the destination(dock, mooring, anchorage etc.)	
$00^{\prime\prime}$ ) and Niulijiao light beacon of Neilingding island (position $22^{\circ}25^{\prime}01^{\prime\prime}$ N,	Pre-departure report	
113° 46′56″ E)	Not less than 0.5 hour before leaving the berth or mooring or heaving	
6. DASHAWEI REPORTING LINE (L6)	up the anchor.	
A line joint the southern end of Dashawei island and Shazaichong estuary	Departure report	
of Shazai island.	After leaving the berth or anchor	
7. DONGGUANJIANG ESTUARY REPORTING LINE (L7)	Other report	
A line joint between Nizhoutoujiao and East Nizhou cable tower.	Vessels involved in any traffic accidents, pollution incidents	
8. DONGJIANG ESTUARY REPORTING LINE (L8)	or anyother emergency situations within Guangzhou VTS Service Area	
A line joint between the northern end of Xinsha wharf and the southern	should report forthwith to GUANGZHOU VTS by VHF or other effective means.	
end of Xingang wharf.	Vessels which intend to use the Lianhuashan eastern channel	
9. TIEZHUANG CHANNEL REPORTING LINE (L9)		
In a position abeam Tiezhuang channel No.75 Buoy.	should report to GUANGZHOU VTS. Inbound vessels should report at	
10. DAHAOZHOU REPORTING LINE (L10)	HUMEN BRIDGE reporting line while outbound vessels should report	
In a position abeam Guangzhou Port East NO. 1Buoy of Dahaozhou channel	on departure from wharf, anchorage and mooring.	
11. HUMEN RRIDGE REPORTING LINE (LH)		

Traffic Service		
Information Service	VTS provides the following services when necessary or upon request: <ol> <li>Verifying vessel position or providing navigational advices in poor visibility or in the event of radar malfunction (on request) 2. tidal information and weather forecast 3. Mmovement of other vessels 4. Port Information, such as the use of fairways swinging basins, berths and anchorages .5. Other information.</li> <li>VTS provide the following Navigational notices or Navigational warnings :</li> <li>Aids to navigation anomalies 2. Fairway changes, traffic blockages or navigational hazards. 3. Weather forecast.</li> <li>Information on vessels engaged in special operation and their works. 5. Advice to keep clear of vessels restricted in her ability to maneuver or engaged in special operation. 6. Other information on navigational safety.</li> </ol>	
Navigational Assistance Service	VTS assists in verifying vessel position on request, but does not give directions or orders.	
Traffic Organization Service	<pre>VTS provides following services when necessary or upon request : 1. On arrival and departure of vessels engaged in special operation. 2. Navigating in inclement weather. 3. Navigating in waters where an accident occurred. 4. Navigating in waters of concern. 5. Others (if situation warrants).</pre>	







